


GRIP DIAGRAM

KEY-105




1. The body of the grip
2. The cover/lid of the grip
3. Connector hole/Fastener
4. The screw of the grip
5. The screw washer of the grip
6. Grip storage

How to Install

WARNING: Make sure the firearm is unloaded before installation.


1. Detach the standard grip using a screwdriver.
Leave the mounting nut inside the receiver, and put the screw and the grip aside.




2. Pull the tab and remove the pistol grip cover (2).



3. Slide the washer (5) onto the grip screw (4). While holding the mounting nut in place, turn the grip screw (4) clockwise to fix it with the receiver.



4. Attach the grip lid (2) back in place.



KEY-105	Length	Width	Height
Dimensions	6.8 cm	3.59 cm	10.95 cm
Weight	110 gr		

TECHNICAL DIMENSIONS

