


GRIP DIAGRAM


KEY-108




1. The body of the grip
2. The cover/lid of the grip
3. Connector hole/Fastener
4. The screw of the grip
5. The screw washer of the grip

How to Install


WARNING: Make sure the firearm is unloaded before installation.



1. Press and pull to remove the grip's cover (2).



2. Install the safety spring detent and the safety spring into the lower receiver and then locate the grip to the exact place.



3. Slide the washer (5) onto the grip screw (4). While holding the mounting nut in place, turn the grip screw (4) clockwise to fix it with the receiver.

4. Attach the grip lid (2) back in place.

KEY-108	Length	Width	Height
Dimensions	7.01 cm	3.06 cm	11.55 cm
Weight	71 gr		

TECHNICAL DIMENSIONS

