



NEXUS-AK

BUTTSTOCK DIAGRAM







How to Install

WARNING: Make sure the firearm is unloaded before installation.



How to change the Folding Direction

1. Press adapter folding button (10) and fold the stock to the left. To change the direction for folding the stock to the right, remove the adapter from the rifle as well as from the buttstock using screw driver. Once the adapter is removed from both receiver and buttstock, rotate the adapter and reinstall it to buttstock and receiver.



2. Once the adapter is rotated and reinstalled, Press adapter folding button (10) and fold the stock to the right.

How to adjust cheek riser



1. Adjust the cheek riser (2) using cheek riser adjustment knobs (3)

NEXUS-AK	Length	Width	Height
Dimensions	26,85 cm	5.25 cm	10.34 cm
Weight	350 gr		

TECHNICAL DIMENSIONS

